



Paper Tape Reader

Reader Coil

PR1 (E1,2,3,4,5)

PR2 (E6,7,8,9)

PR3 (F1,2,3,4)

PR4 (F6,7,8,9)

PR5 (G9)

A1

A2

A3

A4

A5

A6

A7

A8

A9

A10

Tape Reader and Program Relays

Simon		
Drawing 1		
Kevin Murrell	Rev 1.0 28/10/03	Page 1